

## GV2X MKII Digital Meter Manual

### CT Ratio Setting:

1. Press "PROG" in more than 3 sec and system comes into setting interface.
2. Press "+" to increase the CT ratio.
3. Press "-" to decrease the CT ratio.
4. After setting successfully, press "PROG" in more than 3 sec so that the data can be saved and exit from interface. If there is no any operation after 90 sec, the system will exit automatically and data can not be saved.

### Note:

1. If the GV2X model is with "L", then the max secondary CT ratio is 50mA, like GV24L;
2. If the GV2X model is without "L", then the max secondary CT ratio is 5A, like GV24.